


FIG. 1

FIG. 2






FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8

FIG. 9

	SETTING SCREEN	CABLE LABEL EXAMPLE
A	<p>CABLE LABEL PRINTING</p> <p> <input type="radio"/> SEQUENTIAL PRINTING <input checked="" type="radio"/> NO SEQUENTIAL PRINTING ← K1 <input checked="" type="radio"/> TYPE A <input type="radio"/> TYPE B ← K2 <input checked="" type="radio"/> PLUG LABEL FIRST <input type="radio"/> SOCKET LABEL FIRST ← K3 </p>	<div>ABCD</div> <div>ABCD</div>
B	<p>CABLE LABEL PRINTING</p> <p> <input checked="" type="radio"/> SEQUENTIAL PRINTING <input type="radio"/> NO SEQUENTIAL PRINTING <input checked="" type="radio"/> TYPE A <input type="radio"/> TYPE B <input checked="" type="radio"/> PLUG LABEL FIRST <input type="radio"/> SOCKET LABEL FIRST </p>	<div>ABCD ABCD ABCD ABCD ABCD ABCD ABCD ABCD</div> <div>ABCD</div>
C	<p>CABLE LABEL PRINTING</p> <p> <input checked="" type="radio"/> SEQUENTIAL PRINTING <input type="radio"/> NO SEQUENTIAL PRINTING <input type="radio"/> TYPE A <input checked="" type="radio"/> TYPE B <input checked="" type="radio"/> PLUG LABEL FIRST <input type="radio"/> SOCKET LABEL FIRST </p>	<div>ABCD ABCD ABCD ABCD ABCD ABCD ABCD ABCD</div> <div>ABCD 1234</div>
D	<p>CABLE LABEL PRINTING</p> <p> <input checked="" type="radio"/> SEQUENTIAL PRINTING <input type="radio"/> NO SEQUENTIAL PRINTING <input checked="" type="radio"/> TYPE A <input type="radio"/> TYPE B <input type="radio"/> PLUG LABEL FIRST <input checked="" type="radio"/> SOCKET LABEL FIRST </p>	<div>ABCD</div> <div>ABCD ABCD ABCD ABCD ABCD ABCD ABCD ABCD</div>

A1

B1

C1

D1

↑ C10

↑ C2